

EW3705

en

Manual

EW3705-R2 - USB 2.0 Video Grabber

Table of contents

1.0 Introduction	2
1.1 Functions and features	
1.2 Packing contents	
2.0 Installation procedure	
2.1 Installing the software	
2.2 Connecting the hardware	
3.0 Using the ShowBiz DVD software	
3.1 Recording images	
4.0 Using the MediaConverter 4 software	
4.1 Uploading a movie to YouTube	5
4.2 Placing a file on your iPad	6
5.0 Frequently Asked Questions and other related information	
6.0 Service and support	7
7.0 Warning and points of attention	
8.0 Warranty conditions	
9.0 Declaration of Conformity	

1.0 Introduction

Congratulations with the purchase of this high-quality Ewent product! This product has undergone extensive testing by Ewent's technical experts. Should you experience any problems with this product, you are covered by a five-year Ewent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.ewent-online.com and receive product updates!

1.1 Functions and features

The EW3705 USB Video Grabber is a USB adapter which enables you to convert television broadcasts or the contents of video tapes to several media formats. This allows you to burn television programs, old movies or home videos to DVD, put them on YouTube or on your iPad. The supplied software helps you to obtain the best results.

1.2 Packing contents

The following parts need to be present in the packing:

- The EW3705 USB Video Grabber
- Audio/video input cable
- USB extension cable

- CD-ROM with drivers. Arcsoft ShowBiz and Arcsoft MediaConverter
- Manual

2.0 Installation procedure

By following the instructions below you can install the drivers and the additional software of the EW3705 on your computer. We will also explain how to connect the EW3705 to your video devices.

2.1 Installing the software

- Place the supplied installation CD-ROM in the CD-ROM drive or DVD drive of your computer.
- 2. The installation procedure will start automatically.
- Follow the steps shown on screen. During the installation, you need to fill in a name and licensing number. The licensing number can be found on the sleeve of the CD-ROM.
- 4. Restart your computer after the installation.


Note! The license number which will be asked during the installation procedure can be found on the sleeve of the installation CD-ROM.

2.2 Connecting the hardware

Connect the EW3705 to a USB port on your computer. If you wish you can use the USB extension cable for more freedom of movement.

Connect the special plug (from which four cables extend) from the audio/video input cable to the EW3705.

Depending on what device you now wish to connect to the EW3705 (for instance a camera or video recorder) you can use one of the other four plugs of the audio/video input cable. See the image below:



Note! The coupling plugs shown in the image are supplied with the device you wish to connect. You will therefore not find them in the packaging of the EW3705.

3.0 Using the ShowBiz DVD software

The ShowBiz DVD software enables you to convert video images from, for instance, your camera or video recorder to several types of media files. In this chapter we will explain how to transfer the video images to your computer. We will also explain the additional functions of the software.

Note! If you need more help with the different settings you can press the F1 key. A new screen will appear, covering all the possible settings of the software. You will also find more information on the other functions of the software.

During this chapter we will assume you have a video recorder connected to your computer using the EW3705.

3.1 Recording images

- 1. Click 'Start'.
- 2. Click 'Programs' or 'All Programs'.
- 3. Click 'ArcSoft ShowBiz' and open the software.
- 4. The main menu of the software will appear.
- 5. Click the 'Capture' option at the top of the menu.
- 6. Click 'Device Settings' and tab 'Videodecoder'.

- Make sure the correct region is chosen at 'Video Standard'. For Europe, you need to select 'PAL' (B or G).
- 8. Place a mark at 'VCR Input' and click 'OK'.
- 9. At 'Save to' you can select the location or hard disk you want to save the video files to. Using the 'Folder' icon, you can browse to the desired location.

Make sure the selected location or disk has sufficient free disk space. Recording video material requires a lot of free disk space.

- Press the 'Play' button on the VCR. At the right side you will see a small screen which shows a preview of the played video.
- 11. Search for the starting point of the video you want to record.

Note! If you connect certain devices to the EW3705 (for instance a DV camera) a number of buttons will appear (e.g. play, fast forward, rewind.) which allow to search. If these buttons do not appear, you can use the buttons on the device or its remote control.

- 12. Set the duration of the recording at 'Capture Duration'.
- 13. Click the 'Capture' button. The recording will start.
- 14. The recording will stop after the set duration. To manually stop the recording, you need to press 'Stop'.

Hint: In order to create a DVD after making a recording, you need to use the 'Edit' option at the top of the menu. Then you need to use the 'Produce' option at the top of the menu. The software will then show the correct steps.

Note: Ewent is not the manufacturer of the supplied software. Therefore, Ewent can not support the specific settings and functions of the software. If you are experiencing problems using the software, or you have questions regarding the Arcsoft software, you can use the 'Help' function of the software by pressing the 'F1' button on your keyboard. You can also refer to the Arcsoft website for support: www.arcsoft.com

4.0 Using the MediaConverter 4 software

After recording images, you can convert the resulting file to several types of media formats. This allows you to transfer recordings to your Apple iPad, Sony PSP or to your YouTube account. In this chapter we will explain how to upload a recording to your YouTube account and how to convert and transfer a file to your iPad.

4.1 Uploading a movie to YouTube

In this example we will assume you have used ShowBiz to make a recording with a maximum length of 10 minutes and that you saved this recording to your hard disk. We will now explain how to upload this recording to your YouTube account.

- 1. Click 'Start'.
- 2. Click 'Programs' or All Programs'.
- Go to 'ArcSoft MediaConverter Platinum 4' and open the software. A new screen will appear.
- 4. Click on the 'Youtube' icon.
- 5. Your YouTube account settings will be asked. Fill in these settings.
- Click 'Add File' at the top of the menu.
- 7. Browse to the file you want to upload. Select the file and click 'Open'.
- 8. The MediaConverter software starts to convert to a supported format.
- After converting, a screen will appear. You need to fill out some items on this screen and click 'OK'.
- After converting, the MediaConverter software will automatically upload the video file to your YouTube account.

Note! It may take some time (possibly hours) before your movie can actually be found on YouTube. This is caused by the processing time of YouTube.

4.2 Placing a file on your iPad

You can also use the MediaConverter software to transfer files to all kinds of portable media players. In this example, we will transfer a file to an iPad. The MediaConverter software will (if necessary) convert the file to a format which is suitable for your iPad, after which the file will be placed on the iPad. Follow the instructions below:

- 1. Connect your iPad to a USB port on your computer.
- 2. Click 'Start'.
- 3. Click 'Programs' or 'All Programs'.
- Go to 'ArcSoft MediaConverter Platinum 4' and open the software. A new screen will appear.
- 5. In the left part of the screen you will see the software already shows the iPad.
- 6. Place the mouse cursor above the iPad icon and click the 'plus' sign.
- 7. Select the file you wish to upload and click 'Open'.
- The MediaConverter software will now convert the selected file to a supported file format for your iPad.
- 9. You can now upload your movie to your iPad, using iTunes.

Hint: Use the 'Add Device' icon in the top of the menu to add a device which is not shown in the list by default'.

5.0 Frequently Asked Questions and other related information

The latest Frequently asked questions for your product can be found on the support page of your product. Ewent will update these pages frequently to assure you have

the most recent information. Visit www.ewent-online.com for more information about your product.

6.0 Service and support

This users manual has been carefully written by Ewent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.ewent-online.com.

You can also contact us by phone. Below you will find a list with phone numbers for each supported country.

Country Belgium (Dutch)	Phone number 070 277 286	Rate per minute* €0.30
Belgium (French)	070 277 286	€0.30
Denmark	+45 69918565	Local Costs
Finland	+35 8942415826	Local Costs
Germany	(+49) (0)30 887 89 298	Local Costs
Italy	+39 0240042016	Local Costs
Norway	+47 21075033	Local Costs
Spain	807 080 042	€0.41
Sweden	+46 840 309985	Local Costs
The Netherlands	0900-3646368	€0.45
UK	(+44) (0)203 318 9998	Local Costs
Hungary	1-4088902 (From Budapest)	Local Costs
Hungary	06-1-4088902 (From the rest of	Local Costs
Hungary	Hungary) +36 1-4088902 (International)	Local Costs

^{*} Rates mentioned in this table do not include cell phone charges.

7.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual*, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

Repairing of the device should be done by qualified Ewent staff. The warranty immediately voids when products have undergone self repair and/or by misuse. For extended warranty conditions, please visit our website at www.ewent-online.com

*Tip: Ewent manuals are written with great care. However, due to new technological developments it can happen that a printed manual does not longer contain the most recent information.

If you are experiencing any problems with the printed manual or you can not find what you are looking for, please always check our website www.ewent-online.com first for the newest updated manual.

Also, you will find frequently asked questions in the FAQ section. It is highly recommended to consult the FAQ section. Very often the answer to your questions will be found here.

8.0 Warranty conditions

The five-year Ewent warranty applies to all Ewent products unless mentioned otherwise before or during the moment of purchase. When having bought a second-hand Ewent product the remaining period of warranty is measured from the moment of purchase by the product's first owner. The Ewent warranty applies to all Ewent products and parts inextricably connected to and/or mounted on the main product. Power supply adapters, batteries, antennas and all other products not integrated in or directly connected to the main product and/or products of which, without reasonable doubt, can be assumed that wear and tear show a different pattern than the main product are not covered by the Ewent warranty. Products are not covered by the Ewent warranty when subjected to incorrect/improper use, external influences and/or when opened by parties other than Ewent.

9.0 Declaration of Conformity

To ensure your safety and compliance of the product with the directives and laws created by the European Commission you can obtain a copy of the Declaration of Conformity concerning your product by sending an e-mail message to: info@ewent-online.com. You can also send a letter to:

Ewent Europe, PO Box 276, 6160 AG Geleen, The Netherlands. Ewent Italy, Crocevia 12, 39057 Appiano (BZ), Italy.

Clearly state 'Declaration of Conformity' and the article code of the product of which you would like to obtain a copy of the Declaration of Conformity.

EW3705 R2 | 12-2012



Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.
The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



www.ewent-online.com

Ewent is a member of the Eminent Group